


# MODEL AIRBUS BV 691 S - 230 V / 50 Hz

UNIT 1

ILLUSTRATED PARTS BREAKDOWN

From Serial Number: 12940000247


Rev B - May 2020



# MODEL AIRBUS BV 691 S - 230 V / 50 Hz

UNIT 2

ILLUSTRATED PARTS BREAKDOWN



# MODEL BV 691S

## UNIT 3

## PARTS LIST

| N° | CODE     | DESCRIPTION               |
|----|----------|---------------------------|
| 1  | 4240.826 | 1 WAY OUTLET              |
|    | 4240.669 | 4 WAY OUTLET              |
| 2  | 4240.830 | HANDLE                    |
| 3  | 4111.057 | HANDLE CAP                |
| 4  | 4162.934 | BOX COVER HANDLE          |
| 5  | 4240.476 | TRANSPARENT CAP           |
| 6  | 4240.842 | BURNER BOX COVER          |
| 7  | 4240.772 | BURNER BOX CLAMP          |
| 8  | 4240.666 | BURNER STABILIZER         |
| 10 | 4614.001 | BURNER PLUG               |
| 11 | 4514.304 | BURNER                    |
| 12 | 4514.168 | BURNER METAL PLATE        |
| 13 | 4514.616 | BURNER INSULATION PLATE   |
| 14 | 4240.475 | RUBBER CAP                |
| 15 | 4240.770 | CONTROL BOX BRACKET       |
| 16 | 4031.581 | 90° CONNECTION            |
| 17 | 4240.843 | RIGHT SIDE BURNER PANEL   |
| 18 | 4240.273 | CABLE RUBBER PROTECTION   |
| 19 | 4240.995 | LOWER BURNER PANEL        |
| 20 | 4240.845 | LEFT SIDE BURNER PANEL    |
| 21 | 4240.847 | EXTERNAL BURNER PANEL     |
| 22 | 4240.849 | INSULATION BURNER PANEL   |
| 23 | 4240.717 | WIRE HOOK                 |
| 24 | 4117.757 | STRAIGHT CONNECTION       |
| 25 | 4240.590 | 90° CONNECTION            |
| 26 | 4031.120 | FUEL FILTER               |
| 27 | 4240.402 | FUEL FILTER PANEL         |
| 28 | 4034.378 | STRAIGHT CONNECTION       |
| 29 | 4034.257 | METAL CAP                 |
| 30 | 4240.828 | EXTERNAL SIDE PANEL       |
| 31 | 4240.656 | INTERNAL SIDE PANEL       |
| 33 | 4240.634 | INTERNAL INSULATION PANEL |
| 34 | 4240.647 | INTERNAL UPPER BIG PANEL  |
| 35 | 4240.629 | EXTERNAL UPPER BIG PANEL  |
| 36 | 4240.646 | INTERNAL CHIMNEY PANEL    |
| 37 | 4240.631 | EXTERNAL CHIMNEY PANEL    |
| 38 | 4240.436 | REGULATION CHIMNEY PANEL  |
| 39 | 4241.092 | COMBUSTION CHAMBER        |
| 40 | 4241.085 | TURBULIZATOR              |
| 41 | 4240.477 | CHIMNEY CAP               |
| 42 | 4240.624 | EXTERNAL CHAMBER PANEL    |
| 43 | 4240.621 | INSULATION CHAMBER PANEL  |
| 44 | 4240.642 | EXTERNAL BACK PANEL       |
| 45 | 4240.639 | INTERNAL BACK PANEL       |
| 46 | 4240.505 | LIFTING BRACKET           |
| 47 | 4240.191 | CHASSIS CORNER            |
| 48 | 4240.605 | SMALL HORIZONTAL PROFILE  |
| 49 | 4240.834 | FRONT LEFT PROFILE        |
| 50 | 4240.832 | FRONT RIGHT PROFILE       |
| 51 | 4240.838 | LOWER LEFT PROFILE        |
| 52 | 4240.836 | LOWER RIGHT PROFILE       |
| 53 | 4240.613 | BACK LEFT PROFILE         |
| 54 | 4240.611 | BACK RIGHT PROFILE        |
| 55 | 4240.615 | UPPER LEFT PROFILE        |
| 56 | 4240.603 | UPPER RIGHT PROFILE       |

# MODEL BV 691S

## UNIT 3

## PARTS LIST

| N°  | CODE     | DESCRIPTION                  |
|-----|----------|------------------------------|
| 57  | 4240.645 | INTERNAL MOTOR PANEL         |
| 58  | 4241.089 | MOTOR-FAN                    |
| 59  | 4100.656 | NUT                          |
| 60  | 4150.528 | STRAIN RELIEF                |
| 61  | 4514.607 | WIRE PROTECTION              |
| 62  | 4510.855 | SENSOR CLIP                  |
| 63  | 4240.438 | SENSOR BRACKET               |
| 64  | 4240.625 | CHAMBER SUPPORTING BEAM      |
| 65  | 4240.660 | FOOT                         |
| 66  | 4240.637 | LOWER BIG PANEL              |
| 67  | 4240.635 | LOWER SMALL PANEL            |
| 68  | 4514.845 | WHEEL CLIP                   |
| 69  | 5269.401 | WHEEL                        |
| 70  | 4240.773 | AXLE BRACKET                 |
| 71  | 4514.183 | WHEELS AXLE                  |
| 72  | 4240.407 | BURNER WIRE                  |
| 73  | 4160.651 | STRAIN RELIEF                |
| 74  | 4160.648 | MOBILE COVER                 |
| 75  | 4161.401 | MALE PLUG                    |
| 76  | 4161.400 | FEMALE SOCKET                |
| 77  | 4160.647 | 90° COVER                    |
| 78  | 4162.970 | THERMOSTAT CAP               |
| 79  | 4240.577 | FUSE HOLDER                  |
| 80  | 4117.057 | FUSE                         |
| 82  | 4033.905 | LIMIT THERMOSTAT CAP         |
| 83  | 4033.906 | LIMIT THERMOSTAT NUT         |
| 84  | 4240.290 | LIMIT THERMOSTAT             |
| 85  | 4100.656 | NUT                          |
| 86  | 4150.528 | STRAIN RELIEF                |
| 87  | 4260.288 | CAP                          |
| 88  | 4240.405 | METAL BOX                    |
| 89  | 4240.406 | TEMPERATURE SENSOR           |
| 90  | 4240.409 | COMPONENTS BRACKET           |
| 91  | 4240.414 | SWITCH                       |
| 92  | 4240.599 | BYPASS SWITCH                |
| 93  | 4117.058 | LED                          |
| 94  | 4510.414 | TERMINAL BOX                 |
| 95  | 4117.669 | MOBILE TERMINAL BOX          |
| 96  | 4240.138 | CONTACTOR                    |
| 97  | 4240.041 | THERMAL RELAY                |
| 98  | 4240.541 | HOUR COUNTER GASKET          |
| 99  | 4240.540 | ELECTRONIC CONTROLLER GASKET |
| 100 | 4240.663 | ELECTRONIC CONTROLLER        |
| 101 | 4240.416 | HOUR COUNTER                 |
| 102 | 4240.412 | FRONT LABEL                  |
| 103 | 4240.538 | POWER CORD                   |