

Spare Parts for Alucutter 3014

Pos.	Description
1	 <p>Alu Cutter 3014-33 L3</p>
2	 <p>base plate for bow with 0 - 75 °-scale, top base plate for bow with 0 - 75 °-scale, bottom machine screw M6 x 45 mm metal washer, big self-retaining nut</p>
3	 <p>holder for bow with cm-scale 0 - 22 cm, top holder for bow with cm-scale 0 - 22 cm, bottom</p>
4	 <p>allen screw M6 x 30 mm allen screw M6 x 35 mm knurled nut M6, plastic nut M6 self-retaining nut M6 washern big and small, metal and plastic</p>
5	 <p>stopper screw for cutting depth knurled screw, plastic M6 x 25 mm slot nut M6 metal washer, big plastic washer, big</p>
6	 <p>rail, double-layered, 31 cm long, top rail, double-layered, 31 cm long, bottom</p>
7	 <p>stopper plate for cutting depth (angled) allen screw M6 x 20 mm metal washer, big</p>

Spare Parts for Alucutter 3014

Pos.

Description

8



transport restraint, top
transport restraint, bottom

9



hot wire holder, top
plastic holder
metal sleeve
spring
allen screw M4 x 8
nut M4

10



hot wire holder, bottom
plastic holder
metal sleeve
spring
allen screw M4 x 8
nut M4

11



connector on bow for foot switch

12



connector on bow for power supply

13



power supply (transformer)

14




support arm with 1000 mm scale

Spare Parts for Alucutter 3014

Pos.

Description

15



pivot point for support arm, left

16



pivot point detail

allen screw M6 x 25 mm
 plastic washer, big, with large hole
 plastic washer, big, with small hole
 metal washer, big
 self-retaining nut

17



clamping device for °-adjustment of the support arm

18



clamping device in detail

fixing screw with adjusting handle M6 x 60 mm
 metal washer, big
 spacer sleeve, plastic, approx. 40 mm long
 plastic washer
 slot nut M6

19



adjusting screw for 90°-adjustment of the support arm, left

eccenter out of plastic
 machine screw M6 x 20 mm
 metal washer, small

20



limiter (stopper at the end of the support arm)

21



stopper details (the part is a complete unit)

knurled slot, plastic
 plastic washer
 screw with square guide

Spare Parts for Alucutter 3014

Pos.	Description
22	stopper for a fixed measurement
23	stopper in detail (the part is a complete unit)
24	additional support
25	additional support (the part is a complete unit)
26	additional stopper
27	stand with base
28	stabilizer knurled screw M6 x 35 mm machine screw M6 x 20 mm metal washer, small

Spare Parts for Alucutter 3014

Pos.

Description

29



joint

allen screw M6 x 20 mm
metal washer, small
machine screw M6 x 45 mm
self-retaining nut

30



rubber caps for stand

31



fixed support, right
knurled plastic screw, M6 x 35 mm
metal washer, small

32



scaffold bracket
knurled plastic screw M6 x 35 mm
knurled plastic screw M6 x 65 mm
angled plate