




| Key no. | Part no. | Description                         | q'ty | Key no. | Part no. | Description                         | q'ty |
|---------|----------|-------------------------------------|------|---------|----------|-------------------------------------|------|
| 101     | 4512.869 | Front Panel                         | 1    | 202B    | 4512.879 | Motor Gasket                        | 1    |
| 102     | 4512.881 | Rear Panel                          | 1    | 203     | 4512.880 | Power Cord                          | 1    |
| 103     | 4512.890 | Top Cover                           | 1    | 204     | 4512.895 | Compressor Capacitor                | 1    |
| 104     | 4512.865 | Filter                              | 1    | 205     | 4520.107 | Main P.C. Board                     | 1    |
| 105     | 4512.894 | Water Tank                          | 1    | 206     | 4520.108 | Indicator P.C.Board                 | 1    |
| 106     | 4512.851 | Air Deflector                       | 1    | 207     | 4512.734 | Magnet                              | 1    |
| 107     | 4512.870 | Handle                              | 1    | 208     | 4512.737 | Magnetic Switch                     | 1    |
| 108     | 4512.860 | Cover For Light Indicator           | 1    | 209     | 4512.884 | Humidity Sensor                     | 1    |
| 109     | 4512.893 | Water Level Display                 | 1    | 210     | 4520.109 | Copper Temperature Sensor Wire      | 1    |
| 110     | 4512.853 | Bottom Base                         | 1    | 214     | 4520.110 | Pcb For Light Indicator             | 1    |
| 111     | 4520.100 | Air Outlet                          | 1    | 215     | 4520.011 | R290 Sensor Wire (With Copper Head) | 1    |
| 112     | 4512.872 | Left Mat For Top Cover              | 1    | 216     | 4520.010 | Sensor Tube (With Copper Head)      | 1    |
| 113     | 4512.883 | Right Mat For Top Cover             | 1    | 301     | 4512.876 | Metal Clip For Earthing Wire        | 1    |
| 114     | 4512.891 | Top Cover For Main P.C. Board       | 1    | 302     | 4512.896 | Castors                             | 4    |
| 115     | 4512.854 | Bottom Cover For Main P.C. Board    | 1    | 401     | 4512.859 | Cool & Heat Exchanger               | 1    |
| 116     | 4512.864 | Fan Blade                           | 1    | 402     | 4512.861 | Discharging Tube                    | 1    |
| 117     | 4512.756 | Bottom Cover For Sensor             | 1    | 403     | 4512.886 | Suction Tube                        | 1    |
| 119     | 4512.897 | Float                               | 1    | 404     | 4512.720 | Suction Tube For Evaporator         | 1    |
| 120     | 4512.888 | Supporter For Wires Fixing          | 1    | 405     | 4512.862 | Discharging Tube For Condensor      | 1    |
| 122     | 4520.101 | Rubber Plug                         | 4    | 406     | 4512.746 | Refrigerant Charging Tube           | 1    |
| 122A    | 4520.102 | Rubber Plug A                       | 2    | 407     | 4512.863 | Dryer                               | 1    |
| 126     | 4520.103 | Capacitor Protecting Box (Up)       | 1    | 408     | 4520.114 | Capillary                           | 1    |
| 127     | 4520.104 | Capacitor Protecting Box (Down)     | 1    | 409     | 4512.711 | Sheath For Capillary                | 1    |
| 128     | 4520.105 | Safety Box For Motor Capacitor-Down | 1    | 410     | 4512.701 | Thermal Sheath                      | 1    |
| 129     | 4520.106 | Safety Box For Motor Capacitor-Up   | 1    | 501     | 4512.867 | Foam For Water Resist               | 1    |
| 201     | N/A      | Compressor                          | 1    | 809     | 4512.850 | Active Carbon Filter                | 1    |
| 202     | 4512.899 | Motor                               | 1    | 810     | 4520.113 | Name Plate For Control Panel        | 1    |
| 202A    | 4512.878 | Motor Capacitor                     | 1    |         |          |                                     |      |

N/A = Parts not available